SECTION 5: Setup Procedures

CONTENTS

1. Quick Start 5-1

2. NC Insertion Instructions 5-1

3. Centering the Numbering Cylinder 5-2

4. Drive Disk Positioning 5-4

5. Numbering Head Positioning 5-5

6. Installing the Ink Rollers 5-7

7. Positioning the Tripping Cam 5-9

Setup Procedures

1. Quick Start

This section covers basic set-up and operation of the NC-001 and NC-002 numbering systems. These integrated systems, specifically designed for GR Series Risographs, deliver automatic, high-speed, sequential numbering of documents such as forms, tickets, and coupons.

NC systems come standard with the following items:

- One Tripping cam
- One Head holder ring assembly
- Assorted tools for installing and adjusting the Numbering cylinder and heads
- Six Ink rollers (3 red, 3 black).

In addition, you will need at least one 7-digit Numbering head (convex for vertical numbering, straight for horizontal numbering). These are ordered through RISO Customer Service. Remember, you can add up to four heads per ring for a maximum of 12 heads.

Although this section gives you the basics so you can get a quick start into the world of sequential numbering, we recommend reading the complete operation guide before using this accessory in order to achieve optimal results and ensure your complete satisfaction. Also, please use the NC Numbering System video in conjunction with this guide for complete, simple, step-by-step instructions.

2. NC Insertion Instructions

NC numbering systems are the same size as Risograph print cylinders and, therefore, are inserted into the Risograph in the same manner as a print cylinder.



Before inserting the Numbering system, however, please read the instructions on the following pages.